

OAK & WALNUT

Daryl Cushioned Dining Bench

Assembly instructions. Please read before you begin and keep for future reference.


MODEL
YS-4527-120cm
YS-4527-140cm

SIZE
120 cm W × 33 cm D × 45 cm H
140 cm W × 33 cm D × 45 cm H

MATERIAL
FAS-graded solid black walnut legs; artificial leather and foam seat

BEFORE YOU START

In the box



Assembled

TOOLS AND FITTINGS

A	B	C	D
			
Allen key	Hex bolt	Spring washer	Flat washer
5 mm · × 1	M8 × 50 · × 8	Ø8 · × 8	Ø8 · × 8

Protect the surface
Work on a blanket or the flattened carton so the surface is not scratched.

Check the contents
Count the parts against this list. If anything is missing or damaged, contact us before you start.

Lift with two people
Two people are recommended to turn the bench over and stand it upright.

STEP


01

Attach the legs

Lay the seat frame on its side or upside down.

Fit each leg to the matching holes at the four corners.

Secure with the bolts (B), spring washers (C) and flat washers (D) as shown, then tighten with the Allen key (A).



EVERYDAY CARE

Wipe with a soft, dry cloth.

SOLID TIMBER

Walnut moves with the seasons. Check the fittings periodically and tighten if needed.

WARRANTY

10-year warranty on the solid timber structure; 1-year warranty on all other parts. Full terms: oakwalnut.com.au/pages/warranty

Need a hand?

Email info@oakwalnut.com.au · Call 0468 029 833
Please include your order number and model number.
oakwalnut.com.au